



TEAC

AX-505

WARNING - TO AVOID DANGER OF SUFFOCATION, KEEP PARTS FROM CHILDREN
/ / **THIS BAG IS NOT A TOY**



OWNER'S MANUAL
MODE D'EMPLOI
MANUAL DEL USUARIO



20190214

TEAC

AX-505

WARNING - TO AVOID DANGER OF SUFFOCATION, KEEP AWAY FROM BABIES AND CHILDREN. DO NOT USE IN CRIBS, BEDS, CARRIAGES OR PLAY PENS.

THIS BAG IS NOT A TOY

ENGLISH

FRANÇAIS

ESPAÑOL

OWNER'S MANUAL
MODE D'EMPLOI
MANUAL DEL USUARIO







TEAC
RC-1332



TEAC

INPUT SELECTOR
LINE 3

VOLUME (-dB)

Hi-Res
AUDIO

LINE 2 XLR

LINE 1

ON

PHONES

LEFT

RIGHT

STANDBY

AX-505

TEAC

INPUT SELECTOR

LINE 3

LINE 2

LINE 1

XLR

PHONES



TEAC

INPUT

LINE 2

LINE 1

ON

PHONES



STANDBY

Hi-Res
AUDIO

VOLUME (-dB)

0
10
17
19
21
23
26
30
33
38
43
60
∞

20 0 +
dB
100%

RIGHT

AX-505



1. COMMON
2. HOT (+)
3. COLD (-)

INPUT

R XLR L



CAN ICES-3 (B) /
NMB-3 (B)

CAUTION
RISK OF ELECTRIC SHOCK
POSSIBLE FIRE
ATTENTION RISQUE DE CHOC ELECTRIQUE
NE PAS OUVRIR

LINE 3

L

R

LINE 2

LINE 1

INPUTS

SPEAKER
IMPEDANCE
(4-8Ω)



CLASS 2 WIRING


SPEAKERS

~ IN



APPARATEN SKALL
ANSLUAS TILL JORDAT UTTAG.

TRON









TEAC

INPUT SELECTOR
LINE 3

VOLUME (-dB)

Hi-Res
AUDIO

LINE 2 XLR

ON
STANDBY

PHONES

LINE 1

40 20 0
dB
LEFT

40 20 0
dB
RIGHT

0 5 10 15
dB

AX-505

R

VO

XLR



TEAC

INPUT SELECTOR
LINE 3

LINE 2

LINE 1

XLR

ON

PHONES

STANDBY





