





PASS



PASS

XA 100.8

PASS





M

L

Positive (+)

Positive (+)

Negative (-)

Negative (-)

Jumper must be used
with single-ended input

Signal Gnd

12V External Turn-on

CE

Pass Laboratories.

No user serviceable parts inside.

